

Respirator with Valve - Use Instructions



551197 rev A, DATE: 5/10/07
551107a-MaskLocate-wValve-051007gTY.pdf

To test fit:

- a) Cup both hands over the front of the respirator, being careful not to disturb its position.
- b) **Inhale** sharply. If leakage is suspected, adjust position of respirator and/or strap and repeat procedure.

NOTE: Before issuing any respirator to be worn, a face fit test must be performed.